

To flush the Watermaker on Regina Laska

1. Make sure the domestic fresh water pump is switched on at the nav-station



2. Put the valve by the filters into "Flush" mode (moving the level pointing to port, see picture)



3. Open the "Freshwaterflush" valve over the high pressure pump putting it into a horizontal position (pointing to port)



4. Flush for 3 minutes

5. Put the valve by the filters back into “Run” mode (moving the level to pointing forward). See photo



6. Flush for another 30 seconds

7. Close the Freshwaterflush valve over the high pressure pump again, so the level points down (see picture)



8. If you don't use the boat, switch off the Fresh water pump by the navstation again.